
BLITZ FOGGER MODEL BF 90 YARD BOY INSECT FOGGER

FITS ALL 4 CYCLE ENGINES UP TO 4 H.P.



- INSTALLATION INSTRUCTIONS (Read Carefully)
- 1. Remove old muffler from Engine Exhaust Port. (Saaking with penetrating ail far about 2 minutes will moke this easy.) On some engines it may be necessary to remove bolts from corburetor in order to unscrew old muffler. NOTE: On those engines that have 3/1 exhaust port, install a "reducer" (not furnished) as illustrated before connecting muffler to exhaust port.
- 2. Screw diffuser (muffler) up tight to exhaust port. ON SOME MOWERS. IN ORDER FOR DIFFUSER TO CLEAR HANDLE, USE 45° OR 90° ELL. THEN SCREW DIFFUSER TO ELL.
- Screw connector and Metal Tube Assembly into tapped hale in Diffuser neck, as illustrated.
 Tighten securely.
- 4. Screw Feed Volve into BLITZ FOGGER Tonk. Tighten compression nut of feed valve to create drag. Moke certain that Volve is in CLOSED POSITION.
- 5. Install BLITZ FOGGER tank anto handle of power mawer as illustrated with tank straps furnished. Open straps completely with screwdriver, wrop oraund handle and tank with tank in position as shown, insert end of strap into clamp mechanism and screw up tight. Attach neceprene tube anto serroted end of Feed Valve and also anto end of Metal Tube Assembly.
- 6. Fill tonk with BLITZ FOG Insecticide making sure that Feed Valve is in <u>clased</u> positian.
- ** For Lausan, Kahler and Craftsman engines which da not have threaded exhaust, install C2-8 Adapter Plate to engine black with bolts and gosket furnished with side marked "Out" away from engine.

 Then proceed with installation.
- * IMPORTANT: On those installations where supply tank cannot be installed at a minimum height of 2 feet above diffuser, order B22-2 Pressure Pump direct from factory. This will pressurize tank and mointein flow of insecticide into diffuser regardless of position of tank.

HOW TO OPERATE

- 1. Run engine of holf throttle for 3 ta 4 minutes until exhaust is HOT, with Insecticide Feed Volve in clased position.
- 2. TO START FOGGING: Cut Throttle bock to idle and open Insecticide Feed Valve 1/4 turn. It tokes a few seconds for fuel line to fill up.
- 3. If fog does not stort in a few secands, check for air lock by detaching lawer end of Neoprene Tube. This will break air lock and couse fluid to flow. Replace tube as had.
- 4. To check fog, place hand about 2 feet in front of diffuser. Fog should be comporatively "dry" but nat "thin", with a slight glass left an hand. If fog is "wet", you are wasting liquid. To increase value of fog, roise speed af engine and open Insecticide Feed Volve wider.
- 5. DO NOT FOG WHILE MOWING, as best coverage is obtained by placing mower in one spot for 3 or 4 minutes. Keep mower about 3 feet from folioge, utilizing air direction for penetration of area. Then move mower to another spot and repeat procedure until entire premises have been completely fagged.
- Fogging is best dane when breeze is dawn, in early morning ar after dusk. The overage hame area can be campletely
 fogged in 10 to 15 minutes. Treated area may be entered immediately. Pratection lasts for hours. DO NOT FOG ON
 EXPOSED FOODSTUFFS.
- 7. TO STOP FOGGING: Close Insecticide Feed Volve and continue to run engine until exhaust clears. Keep Insecticide Feed Volve closed when not fogging.
- 8. Cleon all parts of fogger ossembly of the end of season.

NOTE: BLITZ FOG "Thermolized" Insecticide is especially formulated for fogging. Using other than recommended BLITZ FOG Insecticide may cause clogging and corrading af fogger ossembly. Far best results, use BLITZ FOG "Thermalized" Insecticide

If your deoler connat supply you with insecticide refills, order directly from the foctory.

One gollon refill — \$4.98 5 gollon drum — \$22.50 prepaid

Send check or money order

No C.O.D.'s

PARTS LIST

C31000-051		Insecticide Supply Tonk	\$3.00
A31000-056		Diffuser (Muffler)	2.00
A31000-055		Connector	.50
A31000-038		Metal Feed tube	.35
B33000-002		Insecticide Feed Valve	1.50
B31000-049		Tonk Strops (2) \$1.25 eo.	2.50
A31000-052		Neaprene tubing = 44"	1.00
A31000-026		Flonge	. 50
B33000-001		Pressure pump (nat furnished)	2.00
A31000-054	×	Brass flare nut	.25
A31000-052		Flonge Gosket	.25
A31000-053		$1/4-20 \times 1/2$ Flonge screws (2)	.25
BF90-8		Instruction Sheet	

No C.O.D.'s - Send check or maney order